

Direct To Film (DTF) Transfer Printing DTFMagic 60PRO Manual Curing Process

1



Prepare your design/file as vector PDF or EPS. Copy, size and nest accordingly.

2



Send file to the printer direct, from the DTFMagic RIP.

3



Once printed, pause and cut film off. Be careful as transfer is still wet.

4



Pre cure printed transfer for 1-2 seconds in the curing oven.

5



Place cured transfer into the Powder Tray. Be sure to cover all the image with adhesive powder.

6



Shake film of excess powder and cure the transfer in the oven for between 80-120 seconds.

7



Pre press the garment to remove any creases and position the transfer.

8



Press at 150°C for 15 seconds.

9



Peel warm or cold, depending on your Film.

10



Seal with release paper or PTFE sheet for matte or gloss finish.