



Transfer Paper has a direction of feed through your laser printer. If your printer model is an A4 size machine it will feed on the short edge of the page - so the correct paper for your machine is A4R. Feeding regular A4 through your machine against the direction of the feed arrows will result in jamming your fuser unit. Please ensure you are ordering the right paper for your machine -if in doubt contact our

Technical Department
on
01582 671444.